

DTC P0717 input shaft speed (ISS) sensor

Circuit Description

The input shaft speed (ISS) sensor is a permanent magnet generator. The ISS sensor mounts in the transmission case in front of the valve body assembly. The sensor faces the reverse clutch housing machined teeth surface. As the reverse clutch housing rotates, an AC voltage is induced and transmitted to the transmission control module (TCM). The AC voltage level and the number of pulses increase as the speed of the reverse clutch housing increases. The TCM converts the AC voltage into a digital signal. The TCM uses the input shaft speed signal to help determine line pressure, transmission shift patterns, torque converter clutch (TCC) slip speed and gear ratio. If the TCM detects no input shaft speed when there is vehicle speed in a drive gear range, then DTC P0717 sets. DTC P0717 is a type B DTC.

Conditions for Running the DTC

- No OSS DTCs P0722 or P0723.
- No engine torque DTC P2637.
- The engine run time is greater than 5 seconds.
- The vehicle speed is greater than 16 km/h (10 mph).

Conditions for Setting the DTC

The transmission input shaft speed is less than 100 RPM for 5 seconds.

Action Taken When the DTC Sets

- The TCM illuminates the malfunction indicator lamp (MIL) during the second consecutive trip in which the Conditions for Setting the DTC are met.
- The TCM commands maximum line pressure.
- The TCM calculates input shaft speed from the output shaft speed sensor and commanded gear.
- The TCM freezes transmission adaptive functions.
- At the time of the first failure, the TCM records the operating conditions

when the Conditions for Setting the DTC are met. The TCM stores this information as a Failure Record.

- At the time of the second failure, the ECM records the operating conditions when the Conditions for Setting the DTC are met. The ECM stores this information as a Freeze Frame.
- The TCM stores DTC P0717 in TCM history.

Conditions for Clearing the MIL/DTC

- The ECM turns OFF the MIL after the sixth consecutive drive trip in which the TCM does not send a MIL illumination request.
- A scan tool can clear the MIL/DTC.
- The TCM clears the DTC from TCM history if the vehicle completes 40 warm-up cycles without an emission related diagnostic fault occurring.
- The TCM cancels the default actions when the ignition is OFF long enough in order to power down the TCM.

Diagnostic Aids

Ensure the ISS is properly torqued to the transmission housing.

Test Description

The numbers below refer to the step numbers on the diagnostic table.

- The resistance measurement will not change if either the ISS high signal circuit or the ISS low signal circuit, but not both, is shorted to ground. The vehicle speed detector in the TCM and the ISS are matched in such a way that an open or a short to ground in the ISS low signal circuit will not usually cause a loss of speed signal or a DTC P0717 to set.
- This step isolates the short between the ISS and the wiring.
- Refer to the latest procedures for TCM reprogramming.

DTC P0717

Step	Action	Value(s)	Yes	No
1	Did you perform the Diagnostic System Check – Vehicle?	—	Go to Step 2	Go to Diagnostic System Check -Vehicle in Vehicle DTC Information

Step	Action	Value(s)	Yes	No
2	<p>1). Install a scan tool.</p> <p>2). Turn ON the ignition with the engine OFF. Important:</p> <ul style="list-style-type: none"> ● Before clearing the DTC, use the scan tool in order to record the ECM Freeze Frame and the TCM Failure Records. Using the Clear Info function erases the Freeze Frame and Failure Records from the ECM and the TCM. ● Using the Clear Info function erases stored DTCs in both the ECM and TCM. <p>3). Record the DTC Freeze Frame and Failure Records.</p> <p>4). Clear the DTC.</p> <p>5). Start the engine.</p> <p>6). Select Transmission ISS on the scan tool.</p> <p>Does the scan tool display input shaft speed above the specified value?</p>	500 RPM	Go to Intermittent Conditions in Engine Controls – 4.6L	Go to Step 3
3	<p>1). Turn OFF the ignition.</p> <p>2). Disconnect the TCM.</p> <p>3). Using the DMM and the J 35616-C GM terminal test kit, measure the resistance between the ISS high signal circuit and the ISS low signal circuit at the TCM.</p> <p>Is the resistance within the specified range?</p>	325–575 W	Go to Step 5	Go to Step 4
4	<p>Test the ISS high signal circuit and ISS low signal circuit for the following conditions:</p> <ul style="list-style-type: none"> ● An open circuit or high resistance condition ● ISS high signal and ISS low signal circuits for a short to voltage or shorted together. <p>Did you find and correct a condition?</p>	—	Go to Step 12	Go to Step 9

Step	Action	Value(s)	Yes	No
5	Measure the resistance between the ISS high signal circuit at the the TCM and ground. Is the resistance greater than the specified value?	50K W	Go to Step 8	Go to Step 6
6	1).Leave the DMM connected. 2).Disconnect the ISS. 3).Measure the resistance between the ISS high signal circuit at the TCM and ground. Is the resistance greater than the specified value?	50K W	Go to Step 9	Go to Step 7
7	Repair the short to ground in the ISS high signal circuit. Did you complete the repair?	—	Go to Step 12	—
8	1).Connect the DMM between the ISS high signal circuit and the ISS low signal circuit at the the TCM. 2).Place the transmission in PARK. 3).Start the engine. Is the AC voltage equal to or greater than the specified value?	0.5 V	Go to Step 11	Go to Step 9
9	1).Remove the ISS. 2).Inspect the ISS and the ISS rotor for the following conditions: <ul style="list-style-type: none"> ● ISS damage ● ISS rotor damage ● Excessive air gap between the reverse clutch input housing assembly (401) rotor and the ISS ● Incorrect alignment between the ISS and the reverse clutch input housing assembly (401) rotor 3).Repair or replace any of the above items as necessary. Did you find and correct a condition?	—	Go to Step 12	Go to Step 10
10	Replace the ISS. Did you complete the replacement?	—	Go to Step 12	—

Step	Action	Value(s)	Yes	No
11	Replace the TCM. Is the action complete?	—	Go to Step 12	—
12	Perform the following procedure in order to verify the repair: 1).Select DTC. 2).Select Clear Info. 3).Start and idle the engine. 4).Observe Transmission ISS on the scan tool. Input speed must be greater than 500 RPM for 2 seconds. 5).Select Specific DTC. 6).Enter DTC P0716. Has the test run and passed?	—	Go to Step 13	Go to Step 2
13	With the scan tool, observe the stored information, capture info and DTC info. Does the scan tool display any DTCs that you have not diagnosed?	—	Go to Diagnostic Trouble Code (DTC) List -Vehicle in Vehicle DTC Information	System OK