

NISSAN ALTIMA L34 2024 Idle Air Quantity Learning

Tested Model: NISSAN ALTIMA L34 2024

Function Description:

This function allows the ECM to learn the position of the IACV-ACC to maintain the engine idle speed. Be sure to execute this mode after replacing the IACV-AAC valve, throttle body, ECM, or when the idle speed or ignition timing is out of the specified range. For details, refer to the service manual.

Execution Conditions:

Before performing this function, confirm that all the following conditions are met. Even for a moment, if any of the conditions are not met, the adjustment process will not be completed.

- Engine speed: >0 and <1200 rpm
- Engine coolant temperature: 70-100 degrees Celsius (158-194 degrees Fahrenheit)
- Vehicle speed: Stopped
- Battery voltage: Greater than 12V (at idle)
- Neutral/Parking gear: On
- Electrical load switches: Off (A/C, headlights, rear window defogger)
- For vehicles equipped with daytime running lights, set the light switch to gear 1, with only the small lights on
- Cooling fan motor: Not running
- Steering wheel: Center position (straight ahead position)

Procedure:

1. On an X431-PAD 5, choose [Local Diagnosis], and then choose [Nissan] to enter the menu (as shown in Figure 1).




Figure 1

2. Choose [Manually Select -> North America -> American Samoa -> ALTIMA -> L34 -> 2024-] in sequence to enter the full vehicle systems, and click [Smart Detection] to scan the full vehicle systems (as shown in Figure 2).




Figure 2

- Choose [System List] and then choose [Engine Control Module (ECM)] (as shown in Figure 3).



Figure 3

- Choose [WORK SUPPORT] (as shown in Figure 4).




Figure 4

5. Choose [Idle Air Quantity Learning] (as shown in Figure 5).




Figure 5

6. Confirm the prompt information and click OK to enter the next step.




Figure 6




Figure 7

7. Click [Start] to learn (as shown in Figure 8).





Figure 8

- The matching precautions are displayed. Choose [Conditions Met] to display the data before learning (as shown in Figure 8).



- The idle air quantity learning status value is displayed as "Completed", and the learning is completed (as shown in Figure 10).



Statement:

The content of this document is copyrighted by LAUNCH TECH CO., LTD., and no individual or organization may quote or reprint it without consent.