

**C0577, C0582, C0587, or C0592 ON
state is less than a preset value, the
DTC will be set immediately**

In order to test for the conditions that set the

DTC C0577, C0582, C0587, or C0592 the following must be present:
The ESC module must first command the strut actuator ON. If the voltage detected in the damper control circuit during the ON state is less than a preset value, the DTC will be set immediately.

LAUNCH