


# Antennas Used to Wake-up Remote Control Key




Key in zones A, B or C will wake-up for external locking and unlocking

Key in zones D or E will wake-up for starting engine

LAUNCH  
LAUNCH



# Compartment Module with Antenn



- Integrated antenna confirms that key is inside vehicle while driving

LAUNCH  
LAU

## Rear Door KG Control Module Antennas



- Each rear door KG control module has an associated antenna
- Antenna output controlled by a CAN signal from EIS

LAUNCH  
LAU