

FIAT Ducato Air Conditioner Relay Command


Supported equipment: Launch's full range of comprehensive diagnostic equipment



Current equipment: PAD V

Functional description: On FIAT, when activating the A/C relay and checking the command electrical default and mechanical operations, it is necessary to perform this program.

Tested model: 2014/Fiat/Ducato, VIN: ZFA25000002B*****

1. On a PAD V, choose [Local Diagnose] and then [FIAT] to test.





FIAT V38.40

Introduction

ECU Coverage:

This Software Diagnoses All FIAT Series ECUs, Including Engine, AT, ABS, SRS, A/C, Instrument, Power Steering, Body PC, Door Control, Tire Pressure Control, Parking Control And Headlamp, Etc.

(The Following Models Covered Are Only For Reference And Will Vary Constantly With The Upgrades Of Software.)

Basic Functions Include:



- Reading ECU Information
- Reading DTCs
- Clearing DTCs
- Reading Vehicle Running Data
- Vehicle component Operation Test

Special functions include:


- Key Programming([Body Module])
- Tire Pressure detection([Body Module]/[Tire Pressure Control])
- Reset Adaption




2. Choose [Automatically Search] to identify car models automatically. After the car model is successfully identified, choose OK.




3. Choose [Yes] to unlock the SGW.




4. Choose [North America] for the region.




5. Input the login user name and password, and click OK.




6. Unlocking is successful. Click OK.





7. Click [Smart Detection] to scan the entire vehicle systems.




8. Click [ECM (Engine Control Module)] to access the system.



9. Click [Special Function] and click OK.




10. Choose [System Test].




11. Choose [Air Conditioner Relay Command].




12. Click OK.




13. Click OK.




14. Click [Continue].




15. Click OK.




16. Click OK.




17. Wait for the countdown to end.



18. Click OK.



19. Click OK. Program execution is completed.



Statement:

The content of this document is copyrighted by Shenzhen Launch Tech Co., Ltd., and no individual or organization may quote or reprint it without consent.