Ford Nautilus Power Seat Position Learn


Supported Equipment: Launch's full range of comprehensive diagnostic equipment

Current Equipment: PRO3 LINK


Function Description: This function is primarily used to memorize and automatically restore the driver's seat position, enhancing driving comfort and convenience.


Tested Model: Ford/2024/Nautilus, VIN: 5LMPJ8JAXRJ ******

1. On a PRO3 LINK, choose [Diagnose].




2. Choose [Ford] to test.







3. Choose [Automatically Search] to identify vehicle models automatically.












4. Tap [Smart Detection] to scan the entire vehicle systems.




5. Tap [DSM (Driver Front Seat Module)] to enter the system.







6. Choose [Special Functions].




7. Choose [Power Seat Position Learn].




8. Turn on the ignition switch.




9. Enter the main menu and choose [Learn Seat Positions].




10. Wait for the security verification to complete.




11. Ensure that the conditions shown below are met before starting diagnostics on this system.




12. Wait for the test to complete.




13. Seat position learning completed.




14. Turn off the ignition switch and exit the program.




15. If [Check Module DTCs (Diagnostic Trouble Codes)] is selected in the main menu at step 9, proceed with the following steps.




16. Turn on the ignition switch.




17. Wait for the module self-test to complete. The following DTC interface will appear.




18. DTCs B1231-54 and B1232-54 are not present, so third-row seat learning is not required.




19. Turn off the ignition switch.



20. Return to the main menu and choose [Exit].



21. Turn off the ignition switch and exit the program.



Statement:

The content of this document is copyrighted by LAUNCH TECH CO., LTD., and no individual or organization may quote or reprint it without consent.