

## 2. OBD系统

### 2.1 与排放相关的诊断信息

×：适用      一：不适用

项目（汽车故障诊断仪屏幕术语）	DTC*1		行程	MIL
	汽车故障诊断仪	ECM*2		
CAN COMM CIRCUIT	U1000	1000*3	2	—
CAN COMM CIRCUIT	U1001	1001*3	2	—
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	P0000	0000	—	—
INT/V TIM CONT-B1	P0011	0011	2	—
INT/V TIM CONT-B2	P0021	0021	2	—
MAF SEN/CIRCUIT	P0102	0102	1	×
MAF SEN/CIRCUIT	P0103	0103	1	×
ECT SEN/CIRC	P0117	0117	2	×
ECT SEN/CIRC	P0118	0118	2	×
TP SEN 2/CIRC	P0122	0122	1	×
TP SEN 2/CIRC	P0123	0123	1	×
H02S1 (B1)	P0132	0132	2	×
H02S1 (B1)	P0134	0134	2	×
H02S2 (B1)	P0138	0138	2	×
H02S1 (B2)	P0152	0152	2	×
H02S1 (B2)	P0154	0154	2	×
H02S2 (B2)	P0158	0158	2	×
TP SEN 1/CIRC	P0222	0222	1	×
TP SEN 1/CIRC	P0223	0223	1	×
KNOCK SEN/CIRC-B1	P0327	0327	2	—
KNOCK SEN/CIRC-B1	P0328	0328	2	—
CKP SEN/CIRCUIT	P0335	0335	2	×
CMP SEN/CIRC-B1	P0340	0340	2	×
CMP SEN/CIRC-B2	P0345	0345	2	×
PW ST P SEN/CIRC	P0550	0550	2	—
ECM	P0605	0605	1 或 2	或 —
ECM BACK UP/CIRCUIT	P1065	1065	2	×
INT/V TIM V/CIR-B1	P1111	1111	2	×
ETC ACTR	P1121	1121	1	×
ETC FUNCTION/CIRC	P1122	1122	1	×

ETC MOT PWR	P1124	1124	1	×
ETC MOT PWR	P1126	1126	1	×
ETC MOT	P1128	1128	1	×
INT/V TIM V/CIR-B2	P1136	1136	2	×
TCS C/U FUNCTN	P1211	1211	2	—
TCS/CIRC	P1212	1212	2	—
ENG OVER TEMP	P1217	1217	1	×
CTP LEARNING	P1225	1225	2	—
CTP LEARNING	P1226	1226	2	—
SENSOR POWER/CIRC	P1229	1229	1	×
ASCD SW	P1564	1564	1	—
ASCD BRAKE SW	P1572	1572	1	—
ASCD VHL SPD SEN	P1574	1574	1	—
NATS MALFUNCTION	P1610 - P1615	1610 - 1615	2	—
CVT C/U FUNCT	P1700	1700	1	—
P-N POS SW/CIRCUIT	P1706	1706	2	×
IN PULY SPEED	P1715	1715	2	—
V/SP SEN (A/T OUT)	P1720	1720	2	—
BRAKE SW/CIRCUIT	P1805	1805	1	×
APP SEN 1/CIRC	P2122	2122	1	×
APP SEN 1/CIRC	P2123	2123	1	×
APP SEN 2/CIRC	P2127	2127	1	×
APP SEN 2/CIRC	P2128	2128	1	×
TP SENSOR	P2135	2135	1	×
APP SENSOR	P2138	2138	1	×

\*1: 第一行程 DTC 编号与 DTC 编号相同。

\*2: 在诊断测试模式 II ( 自诊断结果) 中

\*3: 此 DTC 的故障排除需要汽车故障诊断仪。