



2.3 保险丝电路


F1, F2




F3




F4, F6




F7




F8, 2,5 I



F8, 2,0 I 柴油发动




F9




LAUNCH


F10, 1,8 l 与 2,0 l




F11, F13, F15




F16




F18




F20, F21




F22, F23




F24, F25




F26, F27



F28, F29



F30, F31



LAUNCH