




2.42 内后视镜系统和倒车雷达




0924-01 倒车雷达控制单元1 (R)




0924-03 内后视镜(SH2)




0924-04 倒车雷达蜂鸣器(I)




0924-02 倒车雷达控制单元1 (S2)




0924-05 倒车雷达传感器L(S1)



0924-06 倒车雷达传感器CL(S1)



0924-07 倒车雷达传感器CR(S1)



0924-08 倒车雷达传感器R(S1)

