



42. 零组件图标 (7\124-8\3)


7/124 剎車踏板感知器 XC90




7/129 剎車壓力感知器 2 V70




7/129 剎車壓力感知器 2 XC90




7/130 噴油器側燃油油位感知器 V70




7/130 噴油器側燃油油位感知器 XC90




7/131 駐車輔助感知器 後部 1




7/132 駐車輔助感知器 後部 2




7/133 駐車輔助感知器 後部 3




7/134 駐車輔助感知器 後部 4




7/135 左玻璃破裂感知器




7/136 右玻璃破裂感知器




7/137 尾門玻璃破裂感知器




7/139 剎車壓力感知器 1 V70




7/139 剎車壓力感知器 1 XC90




7/143 泵側燃油油位感知器 V70




7/143 泵側燃油油位感知器 XC90




7/149 雨水感知器模組 (RSM) V70




7/149 雨水感知器模組 (RSM) XC90




7/153 LPG 燃油油位感知器




7/156 CNG 壓力及溫度感知器




7/156 燃油壓力及溫度感知器




7/158 後方大量動作感知器 (MMS)




7/159 空氣品質感知器 (AQS)




7/162 燃油管線壓力感知器 V70




7/162 燃油管線壓力感知器 XC90




7/164 車體感知器組 (BSC)




7/165 壓力及溫度感知器 進氣歧管




7/172 進氣側凸輪軸位置感知器




7/173 曲軸排氣側位置感知器 柴油引擎




7/173 曲軸排氣側位置感知器 汽油引擎




7/175 乘客座重量感知器 安全帶提示器




7/178 右側前撞感知器




7/179 左側前撞感知器




7/201 壓力及溫度感知器 汽油




7/204 駐車輔助感知器 前 5 LHD




7/205 駐車輔助感知器 前 6 LHD




7/206 駐車輔助感知器 前 7 LHD



7/207 駐車輔助感知器 前 8 LHD



8/3 氣候控制系統電磁離合器 V70



8/3 氣候控制系統電磁離合器 XC90

