



43. 零组件图标 (8\6-8\55)


8/6-10 噴油器 柴油引擎




8/6-11 噴油器 汽油引擎




8/17 EGR 閥 V70 柴油引擎




8/17 EGR 閥 XC90 柴油引擎




8/18 EVAP 閥 V70




8/18 EVAP 閥 XC90




8/19 電磁閥 可變閥門正時輸入




8/20 避震器 Four-C 左前




8/21 避震器 Four-C 右前




8/22 避震器 Four-C 左後




8/23 避震器 Four-C 右後




8/28 渦輪增壓控制閥 V70




8/28 渦輪增壓控制閥 XC90




8/30 駕駛座安全氣囊點火器




8/31 乘客側安全氣囊點火器 V70




8/31 乘客側安全氣囊點火器 XC90




8/32 乘客側安全氣囊 2 級點火器 V70




8/32 乘客側安全氣囊 2 級點火器 XC90




8/33 左前安全帶拉力器點火器 V70




8/33 左前安全帶拉力器點火器 XC90




8/34 右前安全帶拉力器點火器 V70




8/34 右前安全帶拉力器點火器 XC90




8/36 排檔鎖電磁線圈




8/37 自排變速箱 AW50




8/37 自排變速箱 4T65AWD




8/38 換檔電磁閥 1 AW50




8/38 換檔電磁閥 1 4T65AWD




8/39 換檔電磁閥 2 AW50




8/39 換檔電磁閥 2 4T65AWD




8/40 鎖止電磁閥 AW50




8/40 鎖止電磁閥 4T65AWD




8/41 壓力電磁閥 AW50




8/41 壓力電磁閥 4T65AWD




8/46 DSTC 啟動單元 V70




8/46 DSTC 啟動單元 XC90




8/51 左前側安全氣囊點火器 V70




8/51 左前側安全氣囊點火器 XC90



8/52 右前側安全氣囊點火器 V70



8/52 右前側安全氣囊點火器 XC90



8/55 左後安全帶緊縮器點火器

