


## 2.7 车身线束—前地板



1	BD003: 车身到顶蓬线束	5	BD006: 车身到驾驶员门线束
2	BD028: 离合器开关	6	BD002: 车身到左仪表板线束 01
3	BD027: 制动踏板开关	7	BD060: 车身到仪表板线束 02
4	BD019: 加速踏板模块	8	BD033: 车身到仪表板线束