

ServiceHints**DEF Rela**

5-3 : Closed with the ignition SW at ON position and the rear window defogger SW on

Junction Block and Wire Harness Connector

Code	Junction Block and Wire Harness (Connector Location)
IG	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)()
IL	
IM _	
3B	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)

Connector Joining Wire Harness and Wire Harness

Code	Joining Wire Harness and Wire Harness (Connector Location)
ID1	Instrument Panel Wire and Floor Wire (Left Kick Panel)

Ground Points

Code	Ground Points Location
IE	Behind the Combination Meter
BJ	Under the Right Quarter Pillar

Splice Points

Code	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
B5	Floor Wire			