



Ignition for 2AZ-FE



RAV4 (EM01M1U)



Ignition for 2AZ-FE

Relay Blocks

Code	Relay Blocks (Relay Block Location)
1	Engine Room R/B No.1 (Engine Compartment Left)

Connector Joining Wire Harness and Wire Harness

Code	Joining Wire Harness and Wire Harness (Connector Location)
AE1	Engine Room Main Wire and Instrument Panel Wire (Left Side of the Instrument Panel)Engine Room Main Wire and Instrument Panel Wire (Left Side of the Instrument Panel)
AE2	Engine Room Main Wire and Instrument Panel Wire (Left Side of the Instrument Panel)
BA1	Engine Wire and Engine Room Main Wire (Inside of the Engine Room R/B No.1 and Engine Room J/B No.1)

Ground Points

Code	See Page	Ground Points Location
A1	65 (2AZ-FE)	Front Left Fender
B1	65 (2AZ-FE)	Left Side of the Cylinder Head

LAUNCH
LAUNCH