Audi A6L Service lamp Reset & Service Interval Set

Service Lamp Reset procedure:

（1） Connect X-431, select [CAN BUS II DIAGNOSTIC CONNECTOR] connector;

（2） Ignition ON;

（3） Select Audi maker;

（4） Select CAN bus system;

（5） Access 17 Instrument cluster;;

（6） Select 10 Adaptation，enter 02 channel, click OK;

（7） Click "-"button to change the adaptation value into "0", click OK；

（8） Exit to end the reset.

Set Interval procedure:

（1） Connect X-431, select [CAN BUS II DIAGNOSTIC CONNECTOR] connector;

（2） Ignition ON;

（3） Select Audi maker;

（4） Select CAN bus system;

（5） Access 17 Instrument cluster；

（6） Select 10 Adaptation，enter 40 channel, click OK;

（7） Select "->" to enter the mileage interval for next service e.g.: input 100 for 5000km，（100=（15000-5000）/100），click OK;

（8） Exit to end the set.

Note: Before change the interval mileage, please verify that the adaptation value in each channel Number: Channel "41" is "0",channel "42" is "150", channel "43" is "150" and channel "44" is"365", otherwise, please modify it as above procedure.