

Power Seat





Junction Block and Wire Harness Connector

| | Code | Junction Block and Wire Harness (Connector Location) |
|---|------|---|
| ı | IQ | Instrument Panel Wire and Instrument Panel J/B (Cowl Side Left) |

Connector Joining Wire Harness and Wire Harness

| Conficetor coming which harmess and which harmess | | |
|---|--|--|
| Code | Joining Wire Harness and Wire Harness (Connector Location) | |
| EK1 | Instrument Panel Wire and Floor Wire (Left Kick Panel) | |

Ground Points

| | Code | Ground Points Location |
|-----|------|------------------------|
| - [| K1 | Left Center Pillar |