

Wireless Code Erasure

Function Description:

This function will delete all registered wireless remotes except for the one you are using.


Attention:


- Ignition is ON.
- Drivers door is open and others are closed.
- Drivers door is unlocked.
- The registration process will fail if the time limit is exceeded for any step.


Instruction:


1).comprises the following steps:











Declare:

The document is owned by the Shenzhen City, the copyright of the LAUNCH Technologies Inc, and no individual or entity shall be quoted or reproduced without consent.

LAUNCH