

# B2213 CCN INTERNAL

- 1). When Monitored:  
With the Instrument Cluster awake.
- 2). Set Condition:  
The Instrument Cluster detects an internal failure.

Possible Causes
1. INSTRUMENT CLUSTER

## Diagnostic Test

- 1). VERIFY INSTRUMENT CLUSTER OPERATION  
With the scan tool, read Cluster DTCs.  
Is DTC: B2213–CABIN COMPARTMENT NODE/CLUSTER INTERNAL active?  
**YES** >> Replace the Instrument Cluster in accordance with the service information.  
Perform BODY VERIFICATION TEST - VER 1.  
**NO** >> Test complete.