

P0130 or P0150 HO2S Circuit

Circuit Description

The wide band heated oxygen sensor (HO2S) measures the amount of oxygen in the exhaust system and provides more information than the switching style HO2S. The wide band sensor consists of an oxygen sensing cell, an oxygen pumping cell, and a heater. The exhaust gas sample passes through a diffusion gap between the sensing cell and the pumping cell. The engine control module (ECM) supplies a voltage to the HO2S and uses this voltage as a reference to the amount of oxygen in the exhaust system. An electronic circuit within the ECM controls the pump current through the oxygen pumping cell in order to maintain a constant voltage in the oxygen sensing cell. The ECM monitors the voltage variation in the sensing cell and attempts to keep the voltage constant by increasing or decreasing the amount of current flow, or oxygen ion flow, to the pumping cell. By measuring the amount of current required to maintain the voltage in the sensing cell, the ECM can determine the concentration of oxygen in the exhaust. The HO2S voltage is displayed as a lambda value. A lambda value of 1 is equal to a stoichiometric air fuel ratio of 14.7:1. Under normal operating conditions, the lambda value will remain around 1. When the fuel system is lean, the oxygen level will be high and the lambda signal will be high or more than 1. When the fuel system is rich, the oxygen level will be low, and the lambda signal will be low or less than 1. The ECM uses this information to maintain the correct air/fuel ratio. If the ECM detects that the HO2S signal voltage is not within range, this DTC sets.

DTC Descriptors

This diagnostic procedure supports the following DTCs.

- DTC P0130 HO2S Circuit Bank 1 Sensor 1
- DTC P0150 HO2S Circuit Bank 2 Sensor 1

Conditions for Running the DTC

- The engine is operating.
- The ignition 1 voltage is between 10.7–18 volts.
- DTC P0130 and P0150 run continuously once the above conditions are met.

Conditions for Setting the DTC

- The ECM detects that the HO2S signal voltage is out of range.

- The above condition exists for less than 1 second.

Action Taken When the DTC Sets

- The control module illuminates the malfunction indicator lamp (MIL) on the second consecutive ignition cycle that the diagnostic runs and fails.
- The control module records the operating conditions at the time the diagnostic fails. The first time the diagnostic fails, the control module stores this information in the Failure Records. If the diagnostic reports a failure on the second consecutive ignition cycle, the control module records the operating conditions at the time of the failure. The control module writes the operating conditions to the Freeze Frame and updates the Failure Records.

Conditions for Clearing the MIL/DTC

- The control module turns OFF the malfunction indicator lamp (MIL) after 4 consecutive ignition cycles that the diagnostic runs and does not fail.
- A current DTC, Last Test Failed, clears when the diagnostic runs and passes.
- A history DTC clears after 40 consecutive warm-up cycles, if no failures are reported by this or any other emission related diagnostic.
- Clear the MIL and the DTC with a scan tool.

Diagnostic Aids

- Use the J 35616-C Connector Test Adapter Kit for any test that requires probing the ECM harness connector or a component harness connector.
- The lower connector of the ECM is connector C1 and the upper connector of the ECM is connector C2. Refer to Engine Controls Component Views on page 6-1209.
- The front wide band sensors do not toggle or switch like a switching HO2S. The front HO2S signals will be relatively stable for an idling engine.
- For an intermittent condition, refer to Intermittent Conditions.
- The following table illustrates the typical voltages for the HO2S circuits:

HO2S Voltages

• Ignition On, Engine Off • HO2S Disconnected	
HO2S Circuit	Voltage
Heater Control	4.6–5.0 V
Heater Supply Voltage	B+
Reference Voltage	2.6–3.1 V
Low Reference	2.2–2.7 V
Pump Current	Less than 0.5 V
Input Pump Current	Less than 0.5 V

Test Description

The numbers below refer to the step numbers on the diagnostic table.

2. This step determines if the condition exists. If there is a condition with the HO2S circuits, the ECM commands open loop for the applicable sensor.
4. This step tests for a bias voltage across the reference voltage circuit and the low reference circuit of the HO2S. The bias voltage that you are measuring, is the voltage difference between the reference voltage circuit and the low reference circuit. If there is a condition with the reference voltage circuit or the low reference circuit of the HO2S, the bias voltage will not be within the specified range, which indicates there is a condition with the circuits.
5. This step tests the input pumping current circuit and the pump current circuit of the HO2S. The input pumping current circuit and the pump current circuit are connected internally within the ECM. If there is a condition with one of the circuits, the other circuit will be affected.

DTC P0130 or P0150

Step	Action	Values	Yes	No
Schematic Reference: Engine Controls Schematics Connector End View Reference: Engine Control Module (ECM) Connector End Views or Engine Controls Connector End Views				
1	Did you perform the Diagnostic System Check–Engine Controls?	—	Go to Step 2	Go to Diagnostic System Check–Engine Controls
2	Important: DTC P0130 is for bank 1 sensor 1 and DTC P0150 is for bank 2 sensor 1 1. Allow the engine to reach operating temperature. 2. Observe the Loop Status Bn. 1 Sen. 1 or Loop Status Bn. 2 Sen. 1 with a scan tool. Does the scan tool display Closed Loop?	—	Go to Step 3	Go to Step 4
3	1. Observe the Freeze Frame/Failure Records for this DTC. 2. Turn OFF the ignition for 30 seconds. 3. Start the engine. 4. Operate the vehicle within the Conditions for Running the DTC. You may also operate the vehicle within the conditions that you observed from the Freeze Frame/Failure Records. Did the DTC fail this ignition?	—	Go to Step 4	Go to Diagnostic Aids

Step	Action	Values	Yes	No
4	<ol style="list-style-type: none"> 1. Turn OFF the ignition. 2. Disconnect the appropriate heated oxygen sensor (HO2S). 3. Turn ON the ignition, with the engine OFF. 4. Measure the voltage between the reference voltage circuit and the low reference circuit of the HO2S with a DMM. <p>Is the voltage within the specified range?</p>	350–550 mV	Go to Step 5	Go to Step 6
5	<p>Measure the voltage between the input pump current circuit and a good ground.</p> <p>Is the voltage within the specified range?</p>	50–90 mV	Go to Step 8	Go to Step 7
6	<ol style="list-style-type: none"> 1. Turn OFF the ignition. 2. Disconnect the engine control module (ECM) harness connectors. 3. Test the reference voltage circuit and the low reference circuit for the following: <ul style="list-style-type: none"> • An open • A short to ground • A short to voltage • High resistance Refer to Circuit Testing and Wiring Repairs in Wiring Systems. <p>Did you find and correct the condition?</p>	—	Go to Step 12	Go to Step 9

Step	Action	Values	Yes	No
7	<p>1. Turn OFF the ignition.</p> <p>2. Disconnect the ECM harness connectors.</p> <p>3. Test the input pump current circuit and pump current circuit for the following:</p> <ul style="list-style-type: none"> • An open • A short to ground • A short to voltage • High resistance Refer to Circuit Testing and Wiring Repairs in Wiring Systems. <p>Did you find and correct the condition?</p>	—	Go to Step 12	Go to Step 9
8	<p>Test for shorted terminals and poor connections at the HO2S. Refer to Testing for Intermittent and Poor Connections and Connector Repairs in Wiring Systems.</p> <p>Did you find and correct the condition?</p>	—	Go to Step 12	Go to Step 10
9	<p>Test for shorted terminals and poor connections at the ECM. Refer to Testing for Intermittent and Poor Connections and Connector Repairs in Wiring Systems.</p> <p>Did you find and correct the condition?</p>	—	Go to Step 12	Go to Step 11
10	<p>Replace the HO2S. Refer to the appropriate procedure:</p> <ul style="list-style-type: none"> • Heated Oxygen Sensor (HO2S) Replacement Bank 1 Sensor 1 • Heated Oxygen Sensor (HO2S) Replacement Bank 2 Sensor 1 <p>Did you complete the replacement?</p>	—	Go to Step 12	—
11	<p>Replace the ECM. Refer to Engine Control Module (ECM) Replacement on page 6-1648. Did you complete the replacement?</p>	—	Go to Step 12	—

Step	Action	Values	Yes	No
12	<ol style="list-style-type: none">1. Clear the DTCs with a scan tool.2. Turn OFF the ignition for 30 seconds.3. Start the engine.4. Operate the vehicle within the Conditions for Running the DTC. You may also operate the vehicle within the conditions that you observed from the Freeze Frame/Failure Records. Did the DTC fail this ignition?	—	Go to Step 2	Go to Step 13
13	Observe the Capture Info with a scan tool. Are there any DTCs that have not been diagnosed?	—	Go to Diagnostic Trouble Code (DTC) List	System OK

LAUNCH