

Programming the engine time conditions for service

This function is intended to Program engine time (hours) parameter. This parameter is used to set the number of hours of the engine may be running before the service reminder indicator (SRI) lights.

Now we take S40(04-) 2008 30786352 AD (ECU Diagnostic Part Number) as an example to illustrate the operation:

Note: The highlight item in the figure indicates corresponding action.




1. step 1: S40(04-)

SELECT MENU			
850			
960			
C70 Coupe			
C70 Conv			
S40 (-04)			
S40 (04-)			
S60			
S70			
PAGE UP		PAGE DOWN	
HOME	BACK	PRINT	HELP
Start			10:25

2. step 2: select year

SELECT MENU			
VIN			
2004			
2005			
2006			
2007			
2008			
PAGE UP		PAGE DOWN	
HOME	BACK	PRINT	HELP
Start			10:26




3. step 3: select DIM

SELECT MENU			
DIM(Driver information module)			
PDM(Passenger door module)			
PSM(Power seat module)			
DDM(Driver door module)			
CCM(Climate control module)			
PHM(Phone module)			
SSM(Steering wheel module)			
AUD(Audio Module)			
PAGE UP		PAGE DOWN	
HOME	BACK	PRINT	HELP
Start			 10:27

4. step 4:




Select: Special Function.

If you can't find the Special Function menu, it means the function has not been developed on your vehicle. Please record the VIN (Vehicle Identification Number) and Version Information (can be read by X431 with the function: Reading off control module ID) and email to Launch (x431@cnlaunch.com). We may work out a solution on how to solve the problem.

Select function			
Reading off control module ID			
Reading off Diagnostic Trouble Codes			
Erasing Diagnostic Trouble Codes			
Parameter display			
Activating components/functions			
Service Reset			
Special Function			
PAGE UP		PAGE DOWN	
HOME	BACK	PRINT	HELP
Start			 10:28

5. step 5:

Select: Programming the engine time conditions for service

Please select special function item			
Resetting the Service reminder indicator(SRI)			
Testing all displays and lamps in instrument			
Programming distance conditions for service			
Programming the time conditions for service			
Programming the engine time conditions for service			
Programming the unit for temperature			
PAGE UP		PAGE DOWN	
HOME	BACK	PRINT	HELP
Start			 15:30

6. step 6:

The information of Programming the engine time conditions for service:

Ignition on


There are three service parameters that can be programmed. This parameter is used to set the number of hours the engine may be running for before the service reminder indicator (SRI) lights.

The following values may be selected:

- 500 hours
- 750 hours
- 1,000 hours
- 1,100 hours


Read off the parameter that is programmed.;

To change the service parameter, mark the desired value in the list and start programming.







7. step 7:

Select Ok then it will send command to ECU, and display information like this:
 Note! If not support information displayed, it will exit this function.



If support, display information like this:

ACTUATION TEST				
Programmed Value		750 hours		
F1: Engine time condition for service = 500 hours				
F2: Engine time condition for service = 750 hours				
F3: Engine time condition for service = 1000 hours				
F4: Engine time condition for service = 1100 hours				
PAGE UP		PAGE DOWN		PRINT
<	F1	F2	F3	F4 >
Start				 15:33

The first line, Programmed Value 750 hours, is the present programmed value for your vehicle, if you want to change this value, you can select the desired value in the list:

F1: Engine time condition for service = 500 hours





F2: Engine time condition for service = 750 hours

F3: Engine time condition for service = 1000 hours

F4: Engine time condition for service = 1100 hours





For example: if you want to change this value to 1000 hours, please select F3 and it will start programming. When programming finish, the Programmed Value will change to 1000 hours as the following figure, it means that the programming succeeds.

Note! Maybe some vehicles can not be programmed. (Programmed Value does not change when programming)

ACTUATION TEST				
Programmed Value		1000 hours		
F1: Engine time condition for service = 500 hours				
F2: Engine time condition for service = 750 hours				
F3: Engine time condition for service = 1000 hours				
F4: Engine time condition for service = 1100 hours				
PAGE UP		PAGE DOWN		PRINT
<	F1	F2	F3	F4 >
Start				 15:36

8. step 8:

When you want to exit this programming, please select EXIT:

ACTUATION TEST				
Programmed Value		1000 hours		
F1: Engine time condition for service = 500 hours				
F2: Engine time condition for service = 750 hours				
F3: Engine time condition for service = 1000 hours				
F4: Engine time condition for service = 1100 hours				
PAGE UP		PAGE DOWN		PRINT
<	F2	F3	F4	EXIT >
Start				 15:37

LAUNCH