Ford Escape Reset the Battery Monitoring Sensor Learned Values


Supported equipment: Launch's full range of comprehensive diagnostic equipment

Current equipment: PAD 5


Function description: This program is used to reset the battery monitoring sensor learned values.


Tested model: Ford/2024/ Escape, VIN: 1FMCU0E11RUA*****

1. On a PAD 5, choose [Local Diagnose].



2. Choose [Ford] to test.





ECU Coverage:


This Diagnostic Software Can Test For USA Ford ECUs, Including: Engine, Automatic Transmission, Anti-Lock Brake, Airbag, Air Conditioning, Dashboard, Anti-Theft, Cruise, Common Electronics, Seats, Light, etc.


- Reading ECUs
 Reading DTCs(Diagnostic trouble code)
 Clearing DTCs(Diagnostic trouble code)
 Reading Vehicle Running Data
 Vehicle Component Operation Test


- Programmable Module Installation
 ESP(Electronic Stability Program) Sensor Calibration
 PCM (Powertrain Control Module) or ICM (Instrument Control Module):
 *Passive Anti-Theft Function (Program Additional Ignition Key, Ignition Key Code Erase And Program, Customer Spare Key Programming Enable/Disable, Parameter Reset,




3. Choose [Automatically Search] to identify car models automatically.









4. Click [Smart Detection] to scan the entire vehicle systems.



5. Click [BCM (Body Control Module)] to access the system.






6. Click [Special Functions].







7. Click [Reset The Battery Monitoring Sensor Learned Values].





8. Click OK. The program for resetting the battery monitoring sensor learned values is completed.





Statement:

The content of this document is copyrighted by LAUNCH TECH CO., LTD., and no individual or organization may quote or reprint it without consent.