

# CHRYSLER Ram3500 Pickup 2018

## Throttle Valve Learning


**Supported equipment:** Launch's full range of comprehensive diagnostic equipment



**Current equipment:** PAD 5

**Function description:** Throttle valve learning executed in CHRYSLER Ram3500 Pickup


**Tested model:** CHRYSLER/2018/Ram3500 Pickup, VIN: 1C6RR6LM5JS2\*\*\*\*\*

1. On a PAD 5, choose [Local Diagnose] and then [CHRYSLER] to test.







2. Choose [Automatically Search] to identify car models automatically.





3. Click OK. It displays a prompt message indicating that the SGW needs to be unlocked.







4. Click [Yes], choose [North America], and input the FCA account you purchased.






5. Click OK.








6. On the PAD 5, click [Smart Detection] to scan the entire vehicle systems.




7. Click [PCM (Powertrain Control Module)] to access the system.



## 8. Click [Special Function].




## 9. Click [Throttle Valve Learn].







10. Click OK.



11. Click OK.



12. Click OK. The operations are completed.



## Statement:

The content of this document is copyrighted by LAUNCH TECH CO., LTD., and no individual or organization may quote or reprint it without consent.